

Remote Display Terminal

The remote terminals utilise the same graphical LCD user interface that can be found on the MxPro 5 series fire panels and are based upon the same advanced, flash based, microprocessor technology.

The MxPro 5 panels and remote terminals can communicate over the same 2-core network cable.

They feature an integral network interface incorporating a special screen termination to prevent mains frequency earth-loop currents flowing between network nodes.

The Ad-NeT network operates as a true peer-to-peer system with full cross panel reporting, control and cause-and-effect functionality of up to 2000 zones.

All remote terminals incorporate buzzer mute, view, enable/disable and test facilities with dedicated system and navigation keys for simple user control.

The display information is fully programmable by individual zone or sector and can display any combination of fires, faults, pre-alarms or plant alarms. E.g. can display all information in its own sector, but can only show fire signals from other sectors of a building.

Features

The RDT has additional control keys for Mute which allows other network panels' warning buzzer to be muted

Fully on-site programmable via onboard alphanumeric keypad or PC configuration tools.

View all information from across the network

By using flash memory and an advanced graphical display, the remote terminals can be easily configured to operate in virtually any language, with any character set and allows for the installer's logo and company details to be displayed on the LCD during normal operation.

Networked for system display or control

Programmable switch input

Graphical LCD display

Ad-NeT/Ad-Net+ compatible

Slide-in labels

Small, robust and compact

24V DC operating voltage

3-year warranty

Disable/enable options.

Approvals

EN54-2:1997 +AC:1999 +A1:2006

EN54-4:1997 +AC:1999 +A1:2002 +A2:2006

Specification

Display	White backlit 240x64 graphical LCD
LED Indicators	1 red (1 x Fire, 1 x Alarm), 1 green (Power) & 3 amber (Fault & System)
Keypad	Alpha numeric keypad, navigation keys & on-board buzzer mute facility
Controls	System keys for Mute
Key-Switch Input	Optional level 2 access enable key switch
Power Supply Input	24 VDC, 115mA (/FT: 150mA) operating range 15-30V
External Supply Monitoring	Monitored external fault input
Number of Fire Zones	2000
USB/Serial Ports	1 x USB
Programming	Via on-board keypad or PC running Windows tools
Enclosure	Steel IP30
Cable Entry	20mm knock-outs. 4 x top and 4 x rear
Colour	RAL 7035
Size H x W x D mm	Enclosure: 218 x 300 x 44 Back box only (when recessing) 218 x 300 x 30
Metalwork Options	Semi flushing bezel, special finishes including stainless & chrome

Order Codes and Options

MX-5010:	(RDT) Remote Display Terminal - Standard network
MX-5010/FT:	(RDT) Remote Display Terminal - Fault Tolerant network
MXM-521:	Semi-Flushing Bezel
MXM-543-BB:	Spare Back-Box
MXM-543-D1:	Spare Panel Cover
MXM-543-D2:	Spare Panel Cover with Key switch aperture

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle upon Tyne, NE12 8EW, UK **T:** +44 (0)345 894 7000 **E:** enquiries@advancedco.com
W: www.advancedco.com

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.