

Remote Battery Temperature Sensor

This peripheral device is a remote battery temperature monitor which should be fitted and used in Rack-Mount and Extended panel enclosures or where batteries are remotely located from the basecard in a separate enclosure.

For Small, Medium, Large & Deep enclosures where batteries are located close to the basecard, the PCB-mounted temperature sensor is suitable.

Features

- Simple to install
- External battery monitoring
- For use with all MxPro 5 series control panels.

Order Codes and Options

MXP-501:	Remote Thermistor for Battery Monitoring
----------	--

Compatibility

Compatible with all MxPro 5 series control panels.

Limitations

The Battery Monitoring cable length must not exceed 500mm.

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle upon Tyne, NE12 8EW, UK **T:** +44 (0)345 894 7000 **E:** enquiries@advancedco.com
W: www.advancedco.com

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.