

1 Loop Smoke Control Panel

SmokeGo control panels provide complete and active smoke control from the fire system. Designed for standalone, dedicated and non-dedicated Control and Indicating Equipment (CIE), by adding a smoke control user interface and loop interface modules, it is possible to achieve automatic and manual control of smoke control fans and dampers.

The control panel consists of a graphical LCD and tactile keypad providing a simple 'select & click' programming aid for engineer configuration and end user operation. Supplied with a single loop-driver card, 2 onboard sounder circuits, 20 programmable zonal LEDs with slide-in labels, and 25 system LEDs for information purposes, there are also 4 programmable function buttons with LED indication for confirmation of operation.

Fan and damper switch cards can be fitted internally or externally to the panel. Up to 15 fan and damper switch cards can be connected per peripheral bus (P-Bus) and expansion options are available for larger systems.

The panel is compatible with AdvancedLive (UK&I only), which is the fire panel monitoring solution that enables secure, easy, real-time management of an Advanced fire system.

Using the PC-NET-022 configuration software, a unique software matrix makes light work of system setup. Graphical representations of the system and a series of drop-down menus mean programming is quick and intuitive.

An extensive suite of user-friendly Windows-based PC software tools are also available to enhance your experience when using SmokeGo (CIE). Configuration, service and logo tools bring additional flexibility and customisation options.

Simply adding a network card allows the panel to communicate with any other SmokeGo or MxPro 5 fire panel, remote terminal, or network peripheral, BMS or graphical interface. The network operates as a true peer-to-peer system and can be configured in a fault-tolerant loop or radial format.

Approvals

EN 54-2:1997 +A1:2006

EN 54-4:1997 +A1:2002 +A2:2006

Certified to EN54 Parts 2 & 4 by FM Approvals

Specification

Base technology	Dual flash-based processors with real-time clock, trace diagnostics, programmable languages and character sets
Display	White backlit 240 x 64 graphical LCD
LED Indicators	22 red (1 x Fire, 1 x More Alarms, 20 x Zonal Programmable), 1 green (Power), 13 amber and 12 bi-colour (Fault & System)

Features

Connectivity to AdvancedLive (UK&I only), Ethernet connection on-board

20 programmable zonal / 20 System LEDs

5 dedicated Smoke Control LEDs

Apollo, Axis EN, Hochiki protocol support

Advanced graphical LCD user interface and support for up to 200 fire zones by default allowing full EN54 compliance without additional hardware

500 smoke compartments and 2000 dampers

Dedicated USB & RS232 Serial Port for direct PC or modem connection

Installer friendly Auto-learn, Loop Detection and Onboard Scope facility

Graphical display configurable for virtually any language

Robust removable equipment chassis with plug-in connectors for simple fixing and cable termination

Integral P-Bus for system expansion via available option cards

Advanced networking, peer-to-peer system, with up to 2000 zones

Programmable push buttons

3-year warranty

Fully programmable

Designed to comply with: ISO 21927-9 and BS7346-8 standards.

Controls	Alpha numeric keypad permitting navigation, Reset, Mute, Silence, Resound, Evacuate, and 4 x programmable push buttons
Protocol	Apollo (XP95 / Discovery), Axis EN & Hochiki ESP
Number of Fire Zones	2000 (200 per individual panel)
Number of Loops	1
Devices per Loop	Protocol dependent
Loop Current	500mA
On-Board Sounder Circuits	2 x 1 Amp programmable
On-Board Relays	2 x 1 Amp 30v AC/DC programmable(10mA, 5v min) - expandable to 4 using MXP-507
Auxiliary Supply	1 x 24v 500mA
Programmable Input	1 x monitored programmable input on-board
Programmable Key Switch Inputs	1 x volt free input (standard enc.), 8 x inputs (M, L, D enc.)
Total Available Output Current	3A maximum available for loop current + sounder outputs + auxiliary supply
Mains Supply	200 - 240v 47-63 Hz AC (+10%, -15% tolerance) 1.0A Max
Charger Current	1A temperature compensated
Ethernet port	10-Base-T, 100-Base-T: AdvancedLive connectivity (UK&I)
Serial Port	1 x on-board RS232 connection for PC, modem, IP, or portable printer
USB Interface	1 x USB B type connection for PC communication
Programming	On-board keypad or PC running Windows tools
Event Log	5000 event & diagnostic + 500 fire
Networking	Optional plug-in network card (MXP-503 - standard, or MXP-509 - fault-tolerant)
Printer (optional)	On-board (M, L, D enclosures only)
Enclosure / Colour	Steel IP30 / RAL7035
Metalwork Options	Flushing bezel, battery box, utility enclosure, termination enclosure and rack mount

Dimensions and Capacity

	Dimensions	Cable Entry	Battery Capacity (internal)	
	H x W x D mm	(20mm knockouts)	Min	Max
Standard	345 x 345 x 85	13 x top, 8 x rear	24v, 4Ah	24v, 7Ah
Large	475 x 450 x 120	19 x top, 11 x rear & 2 x bottom	24v, 4Ah	24v, 18Ah

Order Codes and Options

Enclosure/Protocol	XP95/Discovery	Hochiki ESP	Axis EN
Standard	SC-5101A	SC-5101H	SC-5101V
Large	SC-5101AL	SC-5101HL	SC-5101VL

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle upon Tyne, NE12 8EW, UK **T:** +44 (0)345 894 7000 **E:** enquiries@advancedco.com
W: www.advancedco.com

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.